

TROUBLESHOOTING GUIDE

Retail Stores Group



Lottery Retail Support
1-800-667-1649



RESTART YOUR LOTTERY EQUIPMENT

Before contacting Lottery Retail Support



Lottery Terminal

The standard Lottery Terminal for Lottery tickets, S&W and PROLINE Ticket sales.

Hot tip:

- Keep it clean
- Restart your Lottery Terminal from the on-screen option
- If still an issue, restart using the power button, located at the front of Lottery Terminal at the bottom-right of the base
- Always restart before calling Lottery Retail Support



Lottery Printer

The standard Lottery Printer

Hot tip:

- Keep it clean, don't lean or put items on top of Lottery Printer
- Red light on the front? Printer is out of paper
- No light at all? Check the Printer's power connection
- Turn on the Printer using the button, located at the front of Printer at the bottom-right corner.



Lottery Player Display Unit (PDU):

The standard Lottery Player Display Unit, faces Customer/Player for them to view ticket purchases and validation

Hot tip:

- Keep it clean
- It must face customer
- No light on the front means no power, confirm plug is in both plug and display. Press the power button

**FOR ADDITIONAL
TROUBLESHOOTING**



**Lottery Retail Support
1-800-667-1649**



RESTART YOUR LOTTERY EQUIPMENT

Before contacting Lottery Retail Support



Lottery Ticket Checker

Ticket checker for customer's Lottery, S&W and PROLINE Tickets

Hot tip:

- Keep it clean
- No green light on the front means there is no power, confirm plug is in the wall and in the power block.
- Restart the Ticket Checker with the power button behind the touch screen on the left-hand side
- Always restart before Lottery Retail Support



Lotto Scanner

Connected to Compact Lottery Terminal. Scans Packing Slips, Lottery Tickets, S&W Tickets and Player IDs.

Hot Tip:

- No light on the scanner indicates no power. Check all cable connections and restart the terminal.



Digital Hanging
Jackpot Sign



In-Lane JP Sign

Lottery Digital Jackpot Signage

The standard Lottery Digital Jackpot Signage

If offline or having issues:

- Blinking lights, no lights or jackpot? Confirm it's plugged in
- The Modem, Router, and WAP may need a restart



Keno Display



Media Player

Keno Display and Media Player

The standard Keno Display

If offline or having issues:

- Nothing on Keno Display? Check power, confirm it is plugged in
- Media Player located behind Keno Display,
- Modem, Router, and Switch* (*if installed) may need a restart

FOR ADDITIONAL
TROUBLESHOOTING




Lottery Retail Support
1-800-667-1649



RESTART YOUR LOTTERY EQUIPMENT

Before contacting Lottery Retail Support



Modem(s)

There is one modem located on site (sometimes two), it connects your Lottery Equipment to the Internet that connects to BCLC

If ALL Lottery Equipment is Offline:

- Check that it is plugged in
- Power off/on by unplugging and plugging back in (wait 5 minutes)



Router

There is one Router located on site.

If ALL Lottery Equipment is Offline:

- Check that it is plugged in
- Do not move Cables to different ports
- Power off/on by unplugging and plugging back in (wait 5 minutes)



Switch *optional

Connects your Router to your Lottery Equipment. Required if location has a lot of Lottery Equipment.

If ALL Lottery Equipment is Offline:

- Power off/on by unplugging and plugging back in-Wait 5 minutes
- Do not move Cables to different ports



Wireless Device (WD)

Located under a counter or on the ceiling. Ticket Checkers, Display Screens and Media Players use this to connect to BCLC

If Ticket Checker/Display Screen/Media Player is Offline:

- Modem, Router and Switch may need a restart.
- Power off/on by unplugging and plugging back in the Router. (wait 5 minutes)

**FOR ADDITIONAL
TROUBLESHOOTING**



**Lottery Retail Support
1-800-667-1649**



RESTART YOUR LOTTERY EQUIPMENT

Before contacting Lottery Retail Support



Menu Board



Media Player

Digital Menu Board

RSG LOCATIONS ONLY The standard Digital Menu Board

If offline or having issues:

- Nothing displaying? Check power, confirm it's plugged in
- Media Player located behind Keno Display
- Modem, Router, and Switch* (**if installed*) may need a restart



Lottery Play Stand

SPECIFIC LOCATIONS ONLY Newer Play Stands have a touchscreen Tablet facing the Player

Hot tip:

- Keep it clean – wipe clean with **microfibre cloth and water**
- Restart by unplugging the Lottery Play Stand, wait 10-seconds and plug back in
- Always restart before Lottery Retail Support



Beta Brite Sign



Beta Brite Driver



PoE Injector

Keno Beta Brite Signage

SPECIFIC LOCATIONS ONLY

If offline or having issues:

- No lights or numbers? Confirm it is plugged in
- The Modem, Router, and Switch* (**if installed*) may need a restart

**FOR ADDITIONAL
TROUBLESHOOTING**



**Lottery Retail Support
1-800-667-1649**

