



# Lottery Terminal - “Lock Terminal” Button

Ongoing


The **Lock Terminal** button available on the lottery terminal provides retailer protection without impacting player services.

**A best practice is to always Lock the Terminal when leaving the area and leaving the terminal unattended.**

- ‘Lock Terminal’ signs off the lottery terminal restricting operation but allows peripherals to remain on (versus ‘Sign Off’ where the peripherals shut down). See page two for images of peripherals.
- The button is located to the right of the Sign Off button in the top left corner of the main screen.
- To ‘unlock’ the terminal the Pass # is required using the same Pass # as Sign On.
- As a reminder, the listed contact can call Hotline to change the Pass # to maintain access control.

## Benefits to Retailers

- Security feature to protect against fraudulent transactions.
- Players can still watch Keno and Pacific Hold’em Poker, and use the Self-Serve Terminal even when the lottery terminal is locked.
- Should a selection slip be attempted while the terminal is ‘locked’ the selection slip will be rejected and ‘Feature Unavailable’ will be displayed in the top left corner of the screen.
- ‘Unlock’ the terminal using just the Pass #.
- Sign On News Message only prints on Sign On.
- As per usual, all lottery terminals reset nightly and full Sign On is required every morning at the start of your lottery business day.





# Lottery Terminal - “Lock Terminal” Button

Ongoing

**All peripherals stay ON when ‘Lock Terminal’ button is used.**



Player Display Unit



Keno Boards



Check-A-Ticket Terminal



Self-Serve Terminal

\* The Pacific Hold'em Poker monitor is a satellite feed and remains constant.