

# Payment Card Terminal

## Re-Initialization Instructions

Follow the steps below to synchronize and re-initialize your Moneris payment card terminal.

### V400C

From the **Main Menu**, select:

- **Settings**
- **Software Update**
- **Sync Settings with Moneris**



### Desk/5000


1. On the **Main Menu**, select
  - **Software Update**
  - **Sync with Moneris**

The terminal displays “Syncing your device, please wait” followed by “Sync completed successfully”.

### 2. Tap **OK**

The screen returns to the Software Update menu.

3. Press the **menu**  **key** to return to the Main Menu.



Contact **Moneris** directly at **1-866-319-7450**.

